

Chem-Crest[®] 515

*Near-neutral, mild, ultrasonic liquid
detergent concentrate*



Description

Chem-Crest 515 mild liquid detergent is useful in many applications requiring good detergency and wetting, especially on hard surfaces. It is a non-etching and neutral pH detergent. Chem-Crest 515 was specifically developed for additional particle removal capability. It can also be used as an additive to other detergents to increase wetting capability. Contact your Crest representative for further details.

Substrate Compatibility

Chem-Crest 515 is safe on copper, beryllium copper alloys, brass, gold, silver, stainless steel, aluminum, plastics, glass, nickel alloys, Ceramics, and other materials when used as directed.

Physical Data

Flash Point: None

Specific Gravity: 1.02

pH: 5% solution = 7.5- +/- 0.8

Solubility in Water: Complete

Volatiles: N/A

**These are typical values and do not constitute specifications.

Storage Conditions and Disposal Methods

Avoid freezing conditions. Dispose in accordance with Federal, State, and Local regulations and procedures. No products contained in this concentrate are regulated under SARA Title III, Section 313.

Safety Precautions

See Safety Data Sheet

Operating Conditions

Chem-Crest 515 is used at 3-10% by volume in ultrasonic cleaning applications for light to heavy contaminants. Normal operating temperatures: 130°-160°F. Contact your Crest representative for product-line specific recommendations. Recommended rinsing water temperature: 110 - 150°F.

Typical Contaminants Removed

Chem-Crest 515 removes oils, lubricants, particles, fingerprints, light silicone oils, mold release compounds, buffing compounds and airborne contaminants, as well as other general contaminants.

Availability

Chem-Crest 515 is available in cases of (4) x 1-gallon plastic bottles, 5-gallon pails, and in 55-gallon containers.

For further information on this product, please contact the Chemical Sales Office at:

Crest Ultrasonics Corporation

18 Graphics Drive | Ewing, NJ 08628 | USA

Office +1.609.883.4000 x219

Sjoyce@crest-ultrasonics.com

www.crest-ultrasonics.com

Crest Ultrasonics maintains sales offices in the United States, Malaysia, Singapore, Japan, Germany, the United Kingdom, India, and France.

Our chemicals are blended at our Philadelphia, PA office, Custom Blends, Inc. – A Division of Crest Ultrasonics.

Disclaimer: All statements, technical information and recommendation contained herein are based on tests or other information available to us which we believe to be reliable, but the accuracy or completeness thereof is not guaranteed and are made without representation or warranty. They are presented for your own investigation and verification. Products discussed are sold without warranty, expressed or implied, in law or fact and upon the condition that purchasers make their own tests to determine the suitability of such products to their particular purpose. We shall not be liable for any injury, loss or damage direct or consequential, arising out of use or the inability to use the product. It is the user's obligation and responsibility to determine that any use of the product or the information may infringe on patent rights.