

Chem-Crest[®] 165

Deoxidizing ultrasonic liquid detergent concentrate



Description

Chem-Crest 165 is a phosphate-free deoxidizer and liquid cleaner designed to remove light oils, discoloration, tarnishes, scales and oxides. Solutions are near neutral pH. This detergent also finds uses in the cleaning of soft metals after manufacture, and as part of routine cleaning operations.

Substrate Compatibility

Chem-Crest 165 is compatible with brass, bronze, copper, stainless steel, zinc and aluminum. It is safe on glass, ceramics and plastics. Ferrous surfaces must be protected immediately after treatment with Chem-Crest 165 with an appropriate rust inhibitor.

Physical Data

Flash Point: None

Specific Gravity: 1.02

pH: 5% solution = 5.5- +/- 0.5

Solubility in Water: Complete

Volatiles: N/A

**These are typical values and do not constitute specifications.

Storage Conditions and Disposal Methods

Avoid freezing conditions. Dispose in accordance with Federal, State, and Local regulations and procedures. No products contained in this concentrate are regulated under SARA Title III, Section 313.

Safety Precautions

See Safety Data Sheet

Operating Conditions

Recommended dilution is 5-10% by volume and 10-15% by volume for heavy descaling at temperatures of 150°-180°F. Normal operating temperatures: 130°-160°F. Contact your Crest representative for product-line specific recommendations. Recommended rinsing water temperature: 100 - 150°F.

Typical Contaminants Removed

Chem-Crest 165 removes light oils, light scales and oxides, and general contaminants from the surfaces of parts.

Availability

Chem-Crest 165 is available in cases of (4) x 1-gallon plastic bottles, 5-gallon pails, and in 55-gallon containers.

For further information on this product, please contact the Chemical Sales Office at:

Crest Ultrasonics Corporation

18 Graphics Drive | Ewing, NJ 08628 | USA

Office +1.609.883.4000 x219

Sjoyce@crest-ultrasonics.com

www.crest-ultrasonics.com

Crest Ultrasonics maintains sales offices in the United States, Malaysia, Singapore, Japan, Germany, the United Kingdom, India, and France.

Our chemicals are blended at our Philadelphia, PA office, Custom Blends, Inc. – A Division of Crest Ultrasonics.

Disclaimer: All statements, technical information and recommendation contained herein are based on tests or other information available to us which we believe to be reliable, but the accuracy or completeness thereof is not guaranteed and are made without representation or warranty. They are presented for your own investigation and verification. Products discussed are sold without warranty, expressed or implied, in law or fact and upon the condition that purchasers make their own tests to determine the suitability of such products to their particular purpose. We shall not be liable for any injury, loss or damage direct or consequential, arising out of use or the inability to use the product. It is the user's obligation and responsibility to determine that any use of the product or the information may infringe on patent rights.