

Chem-Crest[®] 400-L

*Petroleum Distillate for ultrasonic
water removal and lubrication*



Description

Chem Crest 400-L is a non-hazardous petroleum distillate designed to be used at full strength in an ultrasonic bath for the primary use of displacing and absorbing rinse water and for the lubrication of weapons and bicycle parts. This solution is designed to absorb large quantities of water which can later be settled out for the purpose of reusing the lubricant.

Typical Contaminants Removed

Chem-Crest 400-L is effective at the removal of water from internal and external surfaces and will lubricate as it does so. Chem-Crest 400-L is the second part of a two-station process used for the cleaning of weapons in the Crest Weapons Cleaning line of products.

Physical Data

Flash Point: 208°F (98°C)

Specific Gravity: 0.8

pH: N/A

Solubility in Water: Slight

Volatiles: N/A

**These are typical values and do not constitute specifications.

Storage Conditions and Disposal Methods

Avoid freezing conditions. Dispose in accordance with Federal, State, and Local regulations and procedures. This product contains glycol ethers (CAS# 68412-54-4) and is regulated under SARA TitleIII, Section 313.

Safety Precautions

See Safety Data Sheet

Operating Conditions

Chem Crest 400-L is designed to be used at full strength, without the need for mixing or shaking prior to use.. Chem Crest 400-L is optimally used between ambient temperature and 130°F in an ultrasonic bath, dependent on the material makeup of the substrate. Contact your Crest representative for product-line specific recommendations.

Substrate Compatibility

Chem Crest 400-L is compatible with metals used in the manufacture of bicycles and firearms.

Availability

Chem-Crest 400-L is available in cases of (4) x 1-gallon plastic bottles, 5-gallon pails, 55-gallon containers., 275-gallon totes, and custom larger sizes.

For further information on this product, please contact the Chemical Sales Office at:

Crest Ultrasonics Corporation

18 Graphics Drive | Ewing, NJ 08628 | USA

Office +1.609.883.4000 x219

Sjoyce@crest-ultrasonics.com

www.crest-ultrasonics.com

Crest Ultrasonics maintains sales offices in the United States, Malaysia, Singapore, Japan, Germany, the United Kingdom, India, and France.

Our chemicals are blended at our Philadelphia, PA office, Custom Blends, Inc. – A Division of Crest Ultrasonics.

Disclaimer: All statements, technical information and recommendation contained herein are based on tests or other information available to us which we believe to be reliable, but the accuracy or completeness thereof is not guaranteed and are made without representation or warranty. They are presented for your own investigation and verification. Products discussed are sold without warranty, expressed or implied, in law or fact and upon the condition that purchasers make their own tests to determine the suitability of such products to their particular purpose. We shall not be liable for any injury, loss or damage direct or consequential, arising out of use or the inability to use the product. It is the user's obligation and responsibility to determine that any use of the product or the information may infringe on patent rights.