



# Crest Ultrasonics Firearm Cleaning System with Slide Lube Pan

## Weapons Cleaning Setup:

The **Chem-Crest 235** solution used in a heated wash tank is specifically designed and engineered to precision-clean firearms. It will quickly remove unburned powder, carbon, lint, oil, & dirt from the weapon parts within 6-10 minutes. Systems feature a unique lube pan that is internally mounted on slide wheels. This makes it easy to transfer the basket straight from the wash solution directly into the lubrication pan. A simple slide of the pan over the wash area of the tank allows transfer of ultrasonic power through the pan and solution and directly to the cleaned components. To complete the process, the parts are moved into an ultrasonic lubrication chamber. A sliding lube pan and a displacement drying agent (**Chem-Crest 400L**) ensures that the parts are moisture free and protected. Firearms are ready for use immediately after completing this step.

## System features include:

- External 40khz/500watt Genesis generator
- Heated wash chamber
- Front panel mounted thermostat and 0-30min. ultrasonic generator control timer
- Primary front-located wash tank
- Sliding internal secondary lube tank
- Individual lift-off tank covers
- Two full-length parts baskets with built-in drip hangers
- Drain valve assembly
- Primary tank supply and return ports for use with external pump filtration system
- Optional 240-volt operation
- Optional roll-around cart
- Optional pump and filter recirculation system



Rifle Cleaning System



Rolling Cart



Overhead View



Optional Pump/Filter



QR Code to Learn More

MODEL	PROCESS TANK	RACK SIZE	U/S POWER	HEAT POWER	TANK CAPACITY	POWER REQUIREMENTS	OVERALL DIMENSIONS	SHIP WEIGHT
F-1236HT	12" x 36" x 6"	11.5" x 35.5" x 5"	1000W	1000W	11.22 Gal	120V/1PH/30AMPS Two plugs (20AMP and 15AMP)	45"x24"	560lbs
F-1236DW	12" x 36" x 6"	11.5" x 35.5" x 5"	1000W	1000W	11.22 Gal	120V/1PH/30AMPS Two plugs (20AMP and 15AMP)	45"x24"	375lbs
F-1236DW-OF	12" x 36" x 6"	11.5" x 35.5" x 5"	1000W	1000W	11.22 Gal	120V/1PH/30AMPS Two plugs (20AMP and 15AMP)	45"x24"	375lbs
F1236DW-NL	12" x 36" x 6"	11.5" x 35.5" x 5"	1000W	1000W	11.22 Gal	120V/1PH/13AMPS 15AMP plug	45"x24"	375lbs
F-1436HT	14" x 36" x 6"	13.5" x 35.5" x 5"	500W	1000W	13 Gal	120V/1PH/14.8AMPS Two 15 AMP plugs	39"x24"	360lbs
F-636HT	6" x 36" x 6"	5.5" x 35.5" x 5"	500W	1000W	5.6 Gal	120V/1PH/23.5AMPS Two plugs (20AMP and 15AMP)	42"x16"	375lbs
2F-636HT	36" x 6" x 8"	35" x 5.5" x 7"	500W Each	1000W Each	5.6 Gal Each	240V/1PH 60Hz / 30AMPS	42"x32" (2x)	950lbs
2F-652HT	52" x 6" x 7"	51.5" x 5.5" x 6"	1000W Each	1000W Each	9.5 Gal Each	120V/1PH/30AMPS Two plugs (20AMP and 15AMP)	56"x24"	800lbs